

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Audiovox	
DC400	Camcorder
Canon	
Digital IXUS 30/40/50/55/60/65	Small Compact
Digital IXUS 330/400/430/500	Small Compact
Digital IXUS 800 / 850 IS	Small Compact
Digital IXUS i5/i/i zoom	Small Compact
Digital IXUS II/IIIs	Small Compact
Digital IXUS v2/v3	Small Compact
Digital IXUS Wireless	Small Compact
Digital IXUS 750	Large Compact
EOS 3	Sorry, no fit
EOS 1D/1D Mark II N/1Ds/1Ds Mark II	Sorry, no fit
EOS 5/10/20/30D/D60	Sorry, no fit
EOS 20Da	Sorry, no fit
EOS 3000N	SLR
EOS 1V	Sorry, no fit
EOS 33V	Sorry, no fit
EOS 50E/Elan IIE	Sorry, no fit
EOS 30V Date	Sorry, no fit
EOS 300V/3000V	SLR
EOS 300/300X/350D/400D/ Rebel XT	SLR
EOS 300D	SLR
EOS 400D	SLR
Powershot A30/60/70/75/80/85/95	Small Compact
Powershot A300/310/400/410/420/430	Small Compact
PowerShot A460	Small Compact
PowerShot A650	Large Compact
Powershot A510/520/530/540/550	Small Compact
PowerShot A560	Small Compact
PowerShot A570	Small Compact
Powershot A700	Large Compact
Powershot A720IS	Large Compact
Powershot A710IS	Small Compact
Powershot A610/A620/A630	Large Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Powershot G1/2/3/6	Large Compact
Powershot G5	SLR or Large Compact
Powershot G7	Large Compact
PowerShot G9	Small Compact
Powershot Pro 1	Sorry, no fit
Powershot S1 IS	SLR or Large Compact
Powershot S2 IS	Sorry, No fit
Powershot S5 IS	SLR or Large Compact
Powershot S3 IS	SLR or Large Compact
Powershot S45/50/60/70/80/410	Small Compact
Powershot SD400/430/450/600	Small Compact
PowerShot A720 IS	Small Compact
PowerShot SD700 / 750	Mini case or Small Hard Lens
PowerShot SD870	Mini case or Small Hard Lens
Powershot SD900	Small Compact
PowerShot SD1000	Mini case or Small Hard Lens
Powershot SD800 IS / 850IS	Mini case or Small Hard Lens
PowerShot SD950	Mini case or Small Hard Lens
PowerShot SX100	Large Compact
Prima Super 90uII/115uII/130u/150u/180 Date	Small Compact
Casio	
Exilim Card EX - S100/600	Small Compact
Exilim Pro EX - P600/700	Small Compact
Exilim Pro EX - P505	Large Compact
Exilim Zoom EX - 750	Small Compact
Exilim Zoom EX - S500	Small Compact
Exilim EX-S880	Mini case or Small Hard Lens
Exilim Zoom EX - Z30	Large Compact
Exilim Zoom EX - Z110/120	Small Compact
Exilim Zoom EX - Z40/55/57/60/70	Small Compact
Exilim EX-Z77 New	Sorry, no fit
Exilim Zoom EX - Z500/600/750/850/1000	Small Compact
Exilim EX-Z1080	Mini case or Small Hard Lens
Exilim EX-Z1200	Small Compact
Exilim EX-V8	Mini case or Small Hard Lens

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Epson** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
QV R41/51/61	Small Compact
Contax	
Aria	SLR
G1/2 Rangefinder	Large Compact
N1 Auto Focus	Sorry, no fit
NX Auto Focus	Sorry, no fit
RTS III	Sorry, no fit
RX II	Sorry, no fit
T Series T3	Small Compact
T Series Tix	Small Compact
T Series TVS III (No JPG image available)	Sorry, no fit
U4R/I4R	Small Compact
Epson	
P-2000/4000	Small Compact
RD1	Small Compact
Fuji	
@xia SlimShot	Small Compact
FinePix A120	Small Compact
FinePix A330/340/345/350/360 Zoom	Small Compact
FinePix A370	Small Compact
FinePix A400/405/410 Zoom	Small Compact
FinePix A403	Small Compact
FinePix A500 Zoom	Small Compact
FinePix A605	Small Compact
FinePix A607 Zoom	Small Compact
FinePix A820	Small Compact
FinePix A900	Small Compact
FinePix A920	Small Compact
FinePix E500/510/550/900 Zoom	Small Compact
FinePix F10/11/30 Zoom	Small Compact
FinePix F40FD	Mini case or Small Hard Lens
FinePix F420/440/450/455/460/470 Zoom	Small Compact
FinePix F480	Mini case or Small Hard Lens

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
FinePix F610/710/810 Zoom	Small Compact
FinePix IS-1	Sorry, no fit
FinePix S1/2/3 Pro	Sorry, no fit
FinePix S5 Pro	Sorry, no fit
FinePix S700	Large Compact
FinePix S20 Pro Zoom	Sorry, no fit
FinePix S3100/5100/5600/7000/9500	Sorry, no fit
FinePix S6000fd	SLR
FinePix S8000fd	SLR
FinePix S9100	SLR
FinePix V10	Small Compact
FinePix Z1/2 Zoom	Small Compact
FinePix Z5fd	Mini case or Small Hard Lens
FinePix Z10fd	Mini case or Small Hard Lens
FinePix Z40fd	Mini case or Small Hard Lens
FinePix Z50fd	Mini case or Small Hard Lens
Fuji Finepix 2650	Large Compact
HP	
Photosmart E317/327	Small Compact
Photosmart M22	Small Compact
Photosmart M417/517	Small Compact
Photosmart M525/527	Small Compact
Photosmart R717/727/817/818/927	Small Compact
Photosmart 945	Sorry, no fit
Kodak	
DC200/210	Large Compact
DC200/210 Plus	Large Compact
DC215/220/240/260/265/280/290	Large Compact
DC3400/3800	Small Compact
DC3200/4800/5000	Large Compact
DCS315/330/420/460/520/560/620/660/760	Sorry, no fit
DCS620/720x	Sorry, no fit
DX-3700	Sorry, no fit
Easyshare C300/310/315/330/360	Small Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Easyshare C340	Large Compact
Easyshare C503/530/533/603/643/663	Small Compact
EasyShare C613	Small Compact
EasyShare C653	Small Compact
Easyshare C875	Small Compact
Easyshare CD33/40/43	Small Compact
Easyshare CW330	Small Compact
Easyshare CX4310	Small Compact
Easyshare CX6230/6300/6330/6445	Small Compact
Easyshare CX7220/7300/7310/7330	Small Compact
Easyshare CX7430/7525/7530	Small Compact
Easyshare DX3215/3500/3600/3700/3900	Small Compact
Easyshare DX4330/4530/7630	Small Compact
Easyshare DX6340/6440/7440	Small Compact
Easyshare DX6490/7590	Large Compact
Easyshare LS633/743/753/755	Small Compact
EasyShare M753	Mini case or Small Hard Lens
EasyShare M853	Mini case or Small Hard Lens
Easyshare P850	Large Compact or SLR
Easyshare P880	Sorry, no fit
EasyShare V1233	Small Compact
EasyShare V1003	Mini case or Small Hard Lens
Easyshare V530/550/603	Small Compact
Easyshare V570/610 Dual Lens	Small Compact
EasyShare V803	Mini case or Small Hard Lens
EasyShare V1253	Mini case or Small Hard Lens
Easyshare Z612/650	Large Compact
Easyshare Z712 IS	SLR
Easyshare Z700/730/740/760	Large Compact
EasyShare Z812	SLR
EasyShare Z885	Small Compact
Easyshare Z7590	Large Compact
EasyShare Z1275	Small Compact
Konica	
KD 100	Small Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
KD 220Z	Small Compact
KD 310Z	Small Compact
KD 400Z	Small Compact
KD 500Z/500G	Small Compact
KD 510Z	Small Compact
Revio C2	Small Compact
Minolta Maxxum 5D	SLR
Minolta A200	Sorry, no fit
Kyocera	
Finecam L3/L3v/L4/L4v/S3L/S3X/S4/S5/S5R	Small Compact
Finecam M410R	Large Compact
Lecia	
M7	
MP	Large Compact
R8/9	Large Compact
C-LUX 2	Mini case or Small Hard Lens
D-LUX 3	Large Compact
CM/CM Zoom	Sorry, no fit
V-Lux 1	SLR
Minolta	
Dimage 5	SLR
Dimage 7/7i/ 7hi	Sorry, no fit
Dimage A1 / A2	Sorry, no fit
Dimage E223	Sorry, no fit
Dimage E323	Small Compact
Dimage F200	Small Compact
Dimage F300	Small Compact
Dimage S414	Small Compact
Dimage xt / xi / x / x20 / x50 / x60	Small Compact
Dimage Z1, Z2/3/20	Small Compact
Dimage Z10	Sorry, no fit
Dynax 303	Large Compact
Dynax 3L	Sorry, no fit

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Dynax 4	SLR
Dynax 404	SLR
Dynax 5	Sorry, no fit
Dynax 7	SLR
Dynax 9	Sorry, no fit
Maxxum 3 QD / 4 QD / 5 QD	Sorry, no fit
Maxxum 500si	SLR
Maxxum 7	Sorry, no fit
Maxxum 7D/700si	SLR
Maxxum 8000i	Sorry, no fit
Maxxum 800si	Sorry, no fit
Maxxum 9	Sorry, no fit
Maxxum HTsi	Sorry, no fit
Maxxum QTsi	SLR
Maxxum STsi (QD)	SLR
Maxxum XTsi	SLR
RD3000	SLR
Riva 140mm	Sorry, no fit
Vectis S-1	Small Compact
Vectis S-100	SLR
X-370	SLR
	Large Compact
Nikon	
AF220/230/240/250	
Coolpix L1	Small Compact
Coolpix L11	Mini case or Small Hard Lens
Coolpix L14	Mini case or Small Hard Lens
Coolpix L15	Mini case or Small Hard Lens
Coolpix P1	Small Compact
Coolpix P50	Small Compact
Coolpix P5100	Small Compact
Coolpix 3100/3200/2100/2000	Small Compact
Coolpix 4.3 (zoom lens too large for compact)	Large Compact
Coolpix 3700/4300/4600/4100/2500	Small Compact
Coolpix 5200	Small Compact
Coolpix 5400/SQ/4500/4800	Small Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Coolpix 7900/775	Large Compact
Coolpix 7600	Small Compact
Coolpix 3500	Small Compact
Coolpix 5900	Small Compact
Coolpix 5000	SLR
Coolpix 8700	Large Compact
Coolpix 5700/8800	Sorry, no fit
Coolpix 880/885/990/995	Sorry, no fit
Coolpix 775	Large Compact
Coolpix S200	Mini case or Small Hard Lens
Coolpix S51	Mini case or Small Hard Lens
Coolpix S50c	Mini case or Small Hard Lens
Coolpix S51c	Mini case or Small Hard Lens
Coolpix S510	Mini case or Small Hard Lens
Coolpix S700	Mini case or Small Hard Lens
D1X/D2X/D2XS	Sorry, no fit
D2H	Sorry, no fit
D40	SLR
D50	SLR
D70	SLR
D80	Sorry, no fit
D 100/200	Sorry, no fit
F100	SLR
F3HP	Sorry, no fit
F4s	Sorry, no fit
F5/F6	Sorry, no fit
F65/ 55/55D	Sorry, no fit
F80D	SLR
F90x	SLR
FM10	Sorry, no fit
FM2N	SLR
FM3A	Sorry, no fit
LiteTouch " 110/ 130/ 150	SLR
LiteTouch Zoom 70w/100w	Small Compact
N55	Small Compact
N60	SLR

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
N65	SLR
N70	SLR
N75	SLR
N80	SLR
N8008s	SLR
N90s	Large Compact
Nuvis Mini1/75i/125i	SLR
OneTouch Zoom 90/90s	Small Compact
Pronea 600i/6i	Small Compact
Pronea S	SLR
Zoom 3120AF	SLR
	Small Compact
Olympus	
700BF/800	
Accura 80	Small Compact
C - 1/ 21/ 100/ 220Z/ 720Z	Small Compact
C - 1Z/ 4/ 8/ 9/ 50/ 51/ 60/ 300	Small Compact
C - 200Z/350Z/860L/990Z	Small Compact
C - 700UZ/720UZ/730UZ	Small Compact
amedia c-60	Small Compact
C - 740/ 960/ 970	Large Compact
C - 765 Ultra Zoom	Large Compact
C - 7000	Large Compact
C- 150/350/500/505	Small Compact
C- 2000Z/2020Z/2040Z/3000	Small Compact
C- 3020Z/3030Z/3040Z/4040/990Z	Large Compact
C- 4000/5050/5060	Large Compact
C- 4040Zoom	Large Compact
C- 740/750/760/765/770/730UZ	Large Compact
C700/C2100UZ	Large Compact
C2500L	Sorry, no fit
C5050Z	Sorry, no fit
C-8080 Wide Zoom	Large Compact
Camedia C-40/50Zoom	Sorry, no fit
D- 560/390/510/550/580/630	Small Compact
D-500L/600L/620L	Small Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
E-1/10/20	Sorry, no fit
E-100RS/	Sorry, no fit
E-400	Large Compact or SLR
IS-20 (QD)	Sorry, no fit
IS-30	Sorry, no fit
IS-5	Sorry, no fit
IS-50	Sorry, no fit
Evolt E-500	SLR
Evolt E-330	SLR
Evolt E-300/	Sorry, no fit
LT Zoom 105/120	SLR
MJU - 1/ II	Small Compact
MJU 300	Small Compact
MJU 400	Small Compact
MJU III Zoom 115/120	Small Compact
MJU Zoom 115/80/140	Small Compact
Newpic 60	Small Compact
FE-115	Small Compact
FE-210	Mini case or Small Hard Lens
FE-230	Mini case or Small Hard Lens
FE-280	Mini case or Small Hard Lens
FE-290	Mini case or Small Hard Lens
OM-2	Small Compact
OZ10	SLR
Stylus 35mm	Small Compact
Stylus 740	Mini case or Small Hard Lens
Stylus 750	Mini case or Small Hard Lens
Stylus 760	Mini case or Small Hard Lens
Stylus 780	Mini case or Small Hard Lens
Stylus 820	Mini case or Small Hard Lens
Stylus 830	Mini case or Small Hard Lens
Stylus 1200	Mini case or Small Hard Lens
SP-510 UZ	Large
SP-550 UZ	SLR
SP-560 UZ	SLR
Stylus Verve	Small Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
 Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
 Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Stylus Zoom 140/400/ 300	Small Compact
Superzoom 700BF / 800	Large Compact
Superzoom 80W/105/120	Small Compact
Zoom 2000	Small Compact
Zoom 310	Large Compact
	Small Compact
Panasonic	
DMC F1/F7	Small Compact
DMC FZ 1/FZ3 / FZ7 /FZ8	SLR
DMC FZ4S/FZ5S	Large Compact or SLR
DMC FZ 5/10/15/20	SLR
Lumix DMC-FZ18 / FZ28	SLR
DMC FZ50	SLR
DMC LZ1/LZ2/LZ2K	Sorry, no fit
DMC LZ6 / LZ7	SLR
DMC LC20	Small Compact
DMC LC40	Small Compact
DMC LC43/33/80	Large Compact
DMC LC5	Small Compact
Lumix DMC-LS75	Small Compact
DMC LX1	Large Compact
Lumix DMC-LX2	Small Compact
DMC FX7/ FX9	Small Compact
Lumix DMC-FX10	Mini case or Small Hard Lens
Lumix DMC-FX12	Mini case or Small Hard Lens
Lumix DMC-FX30 / 33	Mini case or Small Hard Lens
Lumix DMC-FX55	Mini case or Small Hard Lens
Lumix DMC-FX100	Mini case or Small Hard Lens
DMC-FX01	Small Compact
DMC-TZ1 10x Zoom	Small Compact
DMC-TZ3	Large Compact
Pentax	
EI - 100	
EI - 200	Small Compact
EI-2000	Small Compact

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Espon** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
ESPIO 110Zoom/120/140/160	Sorry, no fit
ESPIO 115M Zoom	Large Compact
ESPIO 90MC/ 738G/838/928	Small Compact
A30	Mini case or Small Hard Lens
Optio M40	Mini case or Small Hard Lens
Optio WP	Large Compact
Optio W20/30	Small Compact
Optio E40	Mini case or Small Hard Lens
Optio S /S4/S6	Small Compact
Optio S/330/550/450/33L/330	Small Compact
Optio S5i /S5Z	Small Compact
Optio Z10	Mini case or Small Hard Lens
Lumix DMC-LS75	
115M	Small Compact
160/738G/838/928	Small Compact
Istd	SLR
MZ-S (QD)	SLR
645N	SLR
Pro90 IS	Sorry, no fit
Pz-1p	Sorry, no fit
ZX 30	Sorry, no fit
ZX 5n	Sorry, no fit
ZX 60	SLR
ZX L	SLR
ZX M	SLR
Ricoh	
Caplio R4	No Fit
Ricoh Caplio R6	Small Compact
Caplio G3 /G4	Small Compact
Caplio RR 30/230	Small Compact
Caplio RR1 /RDC-7	Small Compact
RDC-5300	Small Compact
GR - 21	Large Compact
Samsung	

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Digimax 101	Small Compact
Digimax 201/301	Small Compact
Digimax 230/ 350	Small Compact
Digimax 240	Small Compact
Digimax 50 Duo/130/200/V4	Small Compact
Digimax 370	Large Compact
Digimax 330	Large Compact
Digimax S800	Small Compact
L700	Mini case or Small Hard Lens
L730	Mini case or Small Hard Lens
L830	Mini case or Small Hard Lens
L73	Mini case or Small Hard Lens
L74	Small Compact
L77	Small Compact
NV7 OPS	
NV10	Small Compact
NV11	Small Compact
NV20	Small Compact
SDC - 200Z Nexca	Large Compact
i85	Mini case or Small Hard Lens
S630 / 630	Mini case or Small Hard Lens
S85	Small Compact
S1050	Small Compact
SR4000	SLR
S73	Mini case or Small Hard Lens
S730	Mini case or Small Hard Lens
Sanyo	
DSC-J1	Small Compact
Sigma	
SA7N	SLR
SA9	Sorry, no fit
SD9	SLR
SD9/10	Sorry, no fit

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Sony	
DSC-F77/77X/88	Small Compact
DSC-F707/717/828	Sorry, no fit
Cyber-shot DSC-G1	Mini case or Small Hard Lens
DSC-H1/2/5/9	Sorry, no fit
Cyber-shot DSC-H3	
Cyber-shot DSC-H	
DSC-L1/N1	Small Compact
Cybershot DSC-N2	Small Compact
DSC-P1-10/12/32/41/43/52/71/72/73/92/93/93A	Small Compact
DSC-P100/150/200	Small Compact
DSC-R1	Sorry, no fit
DSC-S40/60/80/90	Small Compact
DSC - S75	Large Compact
DSC-S85	Large Compact
DSC-S500	Small Compact
DSC-S700	
Cyber-shot DSC-H3	
DSC-T1/3/5/5N/7/9/30/33	Small Compact
Cyber-shot DSC-T20	Mini case or Small Hard Lens
Cyber-shot DSC-T70	Mini case or Small Hard Lens
Cyber-shot DSC-T100	Mini case or Small Hard Lens
Cyber-shot DSC-T200	Mini case or Small Hard Lens
DSC-U20/30/40	Small Compact
DSC-V1	Small Compact
DSC-V3	Large Compact
DSC-W1/5/7/30/50/70/100	Small Compact
Cybershot DSC-W55	Mini case or Small Hard Lens
Cyber-shot DSC-W80	Mini case or Small Hard Lens
Cybershot DSC-W90	Mini case or Small Hard Lens
Cyber-shot DSC-W200	Mini case or Small Hard Lens
DSLR-A100	SLR